

Wiring for MB AC, AC/DC, DC FIT ALL Race-Tour Ignition switch MBP0153K

If using a Battery with the key in the off position the Battery power is isolated at the headset.
For long term non use of the Scooter, either remove the Battery or disconnect the leads

POSITION 0) Off (key vertical)

POSITION 1) Day light no lights (1st position)

POSITION 2) Day with side lights (2nd position)

POSITION 3) Night full lights (3rd position)

Green - Ignition

Yellow / Green - Earth

Black - Back light and speedo light feed

Grey - Power to side lights

Brown - Main power feed lights (parking on a loop)

Yellow - Side light festoon feed

Orange - Dip Dazzle feed

Red - If using a battery - Main power feed IN from battery DC

Red / White - If using a battery - Main power feed OUT DC